



- Door-opening system for handleless furniture doors
- For drilling into **overlay** doors
- Can only be used in conjunction with Intermat push to open fast-assembly hinges (see pages 3.1.116 - 3.1.121)
- For door widths of 300 - 600 mm and door heights of 300 - 900 mm
- Includes self-adhesive counterplate
- Plastic, self-colour



Product code	PU
9 046 602	100





Counterplate with socket




- For surfaces permitting insufficient adhesion (e.g. oiled or waxed wood)

Product code	PU
0 045 550	1/25

Overlay door



Assembly







- For overlay doors
- Grey plastic
- Push to open Magnet, product code 9 046 602, must be ordered separately, see page 3.1.108

Product code	PU
9 046 976	400



Overlay door



Assembly

