

60cm Freestanding 14 Place **DISHWASHER**

PRODUCT CODE: **EED614TBK**



MADE IN
EUROPE

FEATURES

- + 14 place setting
- + Black finish
- + Slim Panel Design
- + Half load function
- + Extra dry function
- + Turbo Wash
- + Time Delay
- + Concealed heating element
- + Removable top cover
- + 8 Wash programs
- + Intensive 70
- + Eco (45 degrees)
- + Daily (65 degrees)
- + Quick60
- + Mini 35
- + 3.5 star energy rating
- + 4 water rating

SPECIFICATIONS

Water Consumption	13.8L per wash (4 star water rating)
Energy Usage	275 kWh per year, Cold water connection, using ECO program seven times per week (3.5 star energy rating)
Noise Level	47db
Inlet Hose/Drain Hose Length	Inlet hose length 1.55m Drain hose length (expose) 1.72m
Water Connection	Cold water (as dishwasher has its own heating element)
Weight	49.8 kg (gross)/ 44.6 kg (net)
Barcode	9347726028590



eurokitchen



WARRANTY

PRODUCT DIMENSIONS

598mm wide x 598mm depth x 845mm height

KEY FUNCTIONS

14 PLACE SETTINGS

- + With 14-place settings the EED614TBK provides results with greater flexibility allowing you to select the correct setting for your dish-washing requirements.

SIMPLE ELECTRONIC PROGRAM CONTROLLER

- + The EED614TBK dishwasher operates via an electronic push button control. You can select your preferred program by using the rotary knob on the top left of the front panel.

8 WASH PROGRAMS

- + The EED614TBK dishwasher provides you with the choice of 5 different wash programs to ensure you can select the type of wash which best suits whether it be a few dirty dishes to after a large dinner party.

INSTALLATION

Installation is recommended by a qualified installer, please refer to the product manual for full installation instructions.

FILTER CLEANING INFORMATION

Drain pump filter: requires cleaning monthly. This will ensure no interruptions with the dishwasher operation.

