

90cm Ceran Touch Electric COOKTOP

PRODUCT CODE: **ECT900C62**



FEATURES:

- + Smooth Ceran glass electric cooktop
- + Cooktop with double radiant & oval radiant coil
- + 6 hi-lite elements
- + Front sensor touch control operation
- + Overheating detection
- + Auto switch off safety
- + Residual heat indicator
- + 99 minute timer function
- + 9 power stage settings
- + Child lock

KEY FEATURES:

RESIDUAL HEAT INDICATOR

To ensure that you know which electric hotplate is in use, this cooktop is equipped with a heating level indicator. After cooking, there will be some residual heat remaining & the letter "H" will appear to warn you to keep away from burner until it cools down.

CHILD SAFETY LOCK

The child safety lock acts as protection to ensure that your desired temperature cannot be altered without

SENSOR TOUCH CONTROL

The ECT900C62 cooktop is equipped with a stylish touch sensor control panel, adding a touch of style and elegance to your kitchen.

6 HILITE ELEMENTS

This cooktop is fitted with 6 hi-lite elements to ensure rapid heat up.

SMOOTH CERAN GLASS COOKTOP

A high-grade Ceran glass is used for this cooktop to ensure easy cleaning of the smooth Ceran surface.

SPECIFICATIONS:

Electrical Requirements	40 amp dedicated circuit from cooktop to main switchboard
Voltage	220V-240V
Frequency	50Hz/60Hz
Total Rated Load:	6500W - 7800W
Cooking Zones:	
- Front Left Element	1000W/2200W
- Rear Left Element	1100W/ 2600W
- Rear Right Element	1800W
- Front Right Element	1200W
Weight	13.5kg (Gross)/ 11.5kg (Net)
Product Dimensions	W900mm x D520mm x H55mm
Barcode	9347726035697


cooking range

3
YEARS
Warranty

SAFETY INFORMATION

- The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
- Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
- Never leave the appliance unattended when cooking.
- Please refer to the manual for more information

CLEANING AND MAINTENANCE

- Cleaning operations must only be carried out when the appliance is completely cool.
- Clean the appliance regularly, preferably after each use
- Abrasive cleaners or sharp object will damage the appliance surface; you should clean it using water and a little washing up liquid

INSTALLATION DIAGRAM

